

Zapraszamy do kontaktu! Więcej informacji: www.kreski.pl



Speed is Power

M3 MOBILE

UL20 Accessories Guide





Cradle

2 Slot Cradle (2 type) 8 Slot Cradle (2 type) HDMI Cradle



UL20 Series



35 key / 28 key / 53 key Long Range Scanner



Trigger Handle





Vehicle solution

Vehicle Cradle / Forklift Cradle



MISCELLANEOUS

Battery / USB Cable

Hand strap

Stylus Pen

Wire plate

Holster

^{*} More accessories will be added.





UL20-2CRD-CU0

UL20 2-Slot charging & USB host client cradle for 1xUL20 & 1xUL20 spare battery. Requires power supply (UL20-PWSP-2XX; sold separately)

UL20-2CRD-EU0

UL20 2-Slot charging & Ethernet USB host client cradle for 1xUL20 & 1xUL20 spare battery. Requires power supply (UL20-PWSP-2XX; sold separately)









UL20-PWSP-2AU

Power Supply: 100~240VAC, 12VDC, 3A. Provides power to the 2 slot cradle with UL20. Includes AU power cord.

UL20-PWSP-2CN

Power Supply: 100~240VAC, 12VDC, 3A. Provides power to the 2 slot cradle with UL20. Includes CN power cord.

UL20-PWSP-2EU

Power Supply: 100~240VAC, 12VDC, 3A. Provides power to the 2 slot cradle with UL20. Includes EU power cord.

UL20-PWSP-2KR

Power Supply: 100~240VAC, 12VDC, 3A. Provides power to the 2 slot cradle with UL20. Includes KR power cord.

UL20-PWSP-2UK

Power Supply: 100~240VAC, 12VDC, 3A. Provides power to the 2 slot cradle with UL20. Includes UK power cord.

UL20-PWSP-2US

Power Supply: 100~240VAC, 12VDC, 3A. Provides power to the 2 slot cradle with UL20. Includes US power cord.







UL20-8CRD-C00

UL20 8-Slot charging only cradle for 1xUL20 & 1xUL20 spare battery. Requires power supply (UL20-PWSP-8XX; sold separately)

UL20-8CRD-E00

UL20 8-Slot charging & Ethernet cradle for 1xUL20 & 1xUL20 spare battery. Requires power supply (UL20-PWSP-8XX; sold separately)







UL20-PWSP-8AU

Power Supply: 100~240VAC, 12VDC, 12.5A. Provides power to the 8 slot cradle with UL20. Includes AU power cord.

UL20-PWSP-8CN

Power Supply: 100~240VAC, 12VDC, 12.5A. Provides power to the 8 slot cradle with UL20. Includes CN power cord.

UL20-PWSP-8EU

Power Supply: 100~240VAC, 12VDC, 12.5A. Provides power to the 8 slot cradle with UL20. Includes EU power cord.

UL20-PWSP-8KR

Power Supply: 100~240VAC, 12VDC, 12.5A. Provides power to the 8 slot cradle with UL20. Includes KR power cord.

UL20-PWSP-8UK

Power Supply: 100~240VAC, 12VDC, 12.5A. Provides power to the 8 slot cradle with UL20. Includes UK power cord.

UL20-PWSP-8US

Power Supply: 100~240VAC, 12VDC, 12.5A. Provides power to the 8 slot cradle with UL20. Includes US power cord.









View more

UL20-TRIG-S00

Scanning Trigger Handle for UL20

- Reduce wrist fatigue when workers are using terminals for long time.
- Save time by counting stocks in warehouse.
- The design is ergonomically made by measurement in mechanical team.
- The trigger handle has essential functions properly in industrial environments.
- The UL20 and Tigger handle can be removed quickly and easily, depending on the situation.









UL20-VCRD-CU0

UL20 Forklift/Vehicle Charging & USB Host Client Cradle by M3 mounted USB cable. Requires forklift/vehicle mount(UNIV-RAMX; sold separately) **Order Separately: Mount, Voltage Power Converter, cable, Auto Adapter and USB(host, client) cable







UNIV-RAMM


RAM® Double Socket Arm mount for Forklift Cradle

UNIV-RAMM

Clamp base for Forklift Cradle. Attach to the forklift Socket Arm mount.

UNIV-RAMU

U-bolt base for Forklift Cradle. Attach to the forklift Socket Arm mount.




UNIV-CABL-VC

Forklift power extend input cable, Length: 1M

UNIV-PWSP-F00

Forklift Voltage Power Converter, INPUT: DC 24V ~ DC 96.V, OUTPUT: DC 12V / 5A









UL20-VCRD-CU0

UL20 Forklift/Vehicle Charging & USB Host Client Cradle by M3 mounted USB cable. Requires forklift/vehicle mount(UNIV-RAMX; sold separately) **Order Separately: Mount, Voltage Power Converter, cable, Auto Adapter and USB(host, client) cable







UNIV-RAMT


Vehicle Mount for Vehicle Cradle by RAM®. Install in a vehicle by tighten screw.

UNIV-RAMS

Vehicle Mount for Vehicle Cradle by RAM®. Install in a vehicle by suction.

UNIV-PWSP-VVC

Auto Charger Cable: Input 12-24VDC / Output 5VDC, 2A (Cigarette Lighter Adapter) Provides power to vehicle cradle (UL20-VCRD-CU0)



UNIV-CABL-UVH
USB Host Cable for Forklift/Vehicle Cradle
UNIV-CABL-UVC
USB Client Cable for UL20 Forklift/Vehicle Cradle







UL20-BATT-F67

UL20 Frozen Fast Charging Standard Capacity Spare Battery 6,700mAh

*This Battery for UL20F to operate in cold environment

UL20-BATT-S67

UL20W & UL20X Fast Charging Standard Capacity Spare Battery 6,700mAh








UL20-STRP-(S10 or S50)
Hand Strap for UL20 (10 pcs or 50 pcs)

UL20-STYL Spare Stylus with tether for UL20





UL20-WIPL-U00

Wire Plate for UL20, Could be required any rope to use it. Included 2 wire plate and screw.

(1m rope provided by default)

UL20-WIPL-W00

Wire Plate for UL20, Rope length 2 meter.

Included 2 wire plate and screw.







UL20-SCPR
Bullet proof Screen Protector for UL20










Choice of UL20 Functionality for Convenient Use

The following are not accessories, but SKUs are different for each keypad.



The following are not accessories, but SKUs are different for each scanner.



Long Range Scanner
Able to read maximum 21.4 meters
*The SKU of the scanner is divided into 2D and LR.

Angled Scanner (25 degrees)
Helps comfortable aiming
Reduces wrist fatigue with ergonomic design.







USE IT THIS WAY It's the most complete and useful way to use it.

Parcel delivery	- (UL20 + vehicle cradle)	
Warehouse)	UL20 + Trigger Handle + Forklift cradle)	<u>Kr</u> eski
Inventory Management		UL20 + Various Keypad)	Zapraszamy do kontaktu! Więcej informacji: www.kreski.pl
Load and unloading)	UL20 + Wire plate)	
Warehouse Management	• (UL20 + Forklift cradle)	

