



RFD40 Technical Accessory Guide

NOTE: This document is only for general reference. Solutions Pathway and related PMBs should be used for product availability, pricing, and final solution selection.

This document and the information contained therein (Information) are Zebra- confidential, and are provided under, and subject to, the confidentiality provision of your PartnerConnect agreement with Zebra. Any public disclosure (via posting on your website or otherwise) of the Information is strictly prohibited and will be considered a violation of your PartnerConnect agreement with Zebra.

\* Zebra does not endorse or specifically recommend any third-party products, accessories, or hardware. ZEBRA DISCLAIMS ANY AND ALL LIABILITY, INCLUDING ANY EXPRESS OR IMPLIED WARRANTES, WHETHER ORAL OR WRITTEN, FOR SUCH THIRD PARTY PRODUCTS, ACCESSORIES, OR HARDWARE. THE CUSTOMER ACKNOWLEDGES THAT NO REPRESENTATION HAS BEEN MADE BY ZEBRA AS TO THE FITNESS OF THE THIRD-PARTY PRODUCTS, ACCESSORIES, OR HARDWARE FOR THE CUSTOMER'S INTENDED PURPOSE.

Cradles and Charging

Single Device				
Part Number	Picture	Description	Notes	Required Items
CRD1S0T-RFD49-UNIV-CHG-1R	R-	Single Slot Charging ShareCradle - Universal/3rd Party	<ul> <li>Cradle will charge RFD40.</li> <li>Does not charge spare batteries.</li> <li>Includes USB-A port on rear of cradle cup which is reserved for future enhancements.</li> <li>NOTE: Charging cup uses enhanced Zebra common ShareCradle design which allows the cup to be easily removed and swapped with different cups using a simple coin turned screw.</li> </ul>	AC Line Cord (23844-00-00R), or country specific version
CRD1S0T-RFD40-EC5X-CHG-1R		Single Slot Charging ShareCradle - RFD40 and EC50/EC55	<ul> <li>Cradle will charge both RFD40 and EC50/EC55 and supports:         <ul> <li>RFD40 charging by itself</li> <li>EC50/EC55 charging by itself</li> <li>Both RFD40 and EC50/EC55 when attached together</li> <li>Does not charge spare batteries.</li> <li>NOTE: Charging cup uses enhanced Zebra common ShareCradle design which allows the cup to be easily removed and swapped with different cups using a simple coin turned screw.</li> </ul> </li> </ul>	For charging one cradle: ► Power Supply (PWR- BGA12V50W0WW ► DC Line Cord (CBL-DC-388A1- 01) ► AC Line Cord (23844-00-00R), or country specific version For charging up to 4 cradles from one power supply: ► Power Supply (PWR- BGA12V108W0WW) ► 4-Way DC Line Cord (CBL-DC- 380A1-01) ► AC Line Cord (23844-00-00R
CRD1S0T-RFD40-TC2X-CHG-1R		Single Slot Charging ShareCradle - RFD40 and TC21/TC26	<ul> <li>Cradle will charge both RFD40 and TC21/TC26 and supports:         <ul> <li>RFD40 charging by itself</li> <li>TC21/TC26 charging by itself</li> <li>Both RFD40 and TC21/TC26 when attached together</li> <li>Does not charge spare batteries.</li> <li>NOTE: Charging cup uses enhanced Zebra common ShareCradle design which allows the cup to be easily removed and swapped with different cups using a simple coin turned screw.</li> </ul> </li> </ul>	For charging one cradle: ► Power Supply (PWR- BGA12V50W0WW ► DC Line Cord (CBL-DC-388A1- 01) ► AC Line Cord (23844-00-00R), or country specific version For charging up to 4 cradles from one power supply: ► Power Supply (PWR- BGA12V108W0WW) ► 4-Way DC Line Cord (CBL-DC- 380A1-01) ► AC Line Cord (23844-00-00R

**刹 ZEBRA** 



Zapraszamy do kontaktu! Więcej informacji: www.kreski.pl

CRD1S0T-RFD49-UNIV-COM-1R	RECORD RECORD	Single Slot Charge- Communication ShareCradle - Universal/3rd Party	<ul> <li>Cradle will charge RFD40.</li> <li>Also provides USB communication to RFD40.</li> <li>Does not charge spare batteries.</li> <li>Includes USB-A port on rear of cradle cup which is reserved for future enhancements.</li> <li>NOTE: Charging cup uses enhanced Zebra common ShareCradle design which allows the cup to be easily removed and swapped with different cups using a simple coin turned screw.</li> </ul>	For charging one cradle: ► Power Supply (PWR- BGA12V50W0WW ► DC Line Cord (CBL-DC-388A1- 01) ► AC Line Cord (23844-00-00R), or country specific version For charging up to 4 cradles from one power supply: ► Power Supply (PWR- BGA12V108W0WW) ► 4-Way DC Line Cord (CBL-DC- 380A1-01) ► AC Line Cord (23844-00-00R ► USB Cable (25-124330-01R) for PC connection
CRD1S0T-RFD40-EC5X-COM-1R		Single Slot Charge- Communication ShareCradle - RFD40 and EC50/EC55	<ul> <li>Cradle will charge both RFD40 and EC50/EC55 and supports:</li> <li>RFD40 charging by itself</li> <li>EC50/EC55 charging by itself</li> <li>Both RFD40 and EC50/EC55 when attached together</li> <li>Also provides USB communication to RFD40, not EC50/EC55.</li> <li>Does not charge spare batteries.</li> <li>NOTE: Charging cup uses enhanced Zebra common ShareCradle design which allows the cup to be easily removed and swapped with different cups using a simple coin turned screw.</li> </ul>	For charging one cradle: Power Supply (PWR- BGA12V50W0WW ►DC Line Cord (CBL-DC-388A1- 01) ►AC Line Cord (23844-00-00R), or country specific version For charging up to 4 cradles from one power supply: Power Supply (PWR- BGA12V108W0WW) ►4-Way DC Line Cord (CBL-DC- 380A1-01) ►AC Line Cord (23844-00-00R ►USB Cable (25-124330-01R) for PC connection
CRD1S0T-RFD40-TC2X-COM-1R		Single Slot Charge- Communication ShareCradle - RFD40 and TC21/TC26	<ul> <li>Cradle will charge both RFD40 and TC21/TC26 and supports:         <ul> <li>RFD40 charging by itself</li> <li>TC21/TC26 charging by itself</li> <li>Both RFD40 and TC21/TC26 when attached together</li> </ul> </li> <li>Also provides USB communication to RFD40, not TC21/TC26.</li> <li>Does not charge spare batteries.</li> <li>NOTE: Charging cup uses enhanced Zebra common ShareCradle design which allows the cup to be easily removed and swapped with different cups using a simple coin turned screw.</li> </ul>	For charging one cradle: ► Power Supply (PWR- BGA12V50W0WW ► DC Line Cord (CBL-DC-388A1- 01) ► AC Line Cord (23844-00-00R), or country specific version For charging up to 4 cradles from one power supply: ► Power Supply (PWR- BGA12V108W0WW) ► 4-Way DC Line Cord (CBL-DC- 380A1-01) ► AC Line Cord (23844-00-00R ► USB Cable (25-124330-01R) for PC connection
CRD1S0T-RFD49-BASE-CHG-1R		Single Slot Charging ShareCradle Base	<ul> <li>Includes Charge-Only Base for attaching Cradle cup.</li> <li>Does not charge spare batteries.</li> <li>NOTE: Base accepts Charging cups using enhanced Zebra common ShareCradle design which allows the cup to be easily removed and swapped with different cups using a simple coin turned screw.</li> </ul>	<ul> <li>► Cradle Cup</li> <li>For charging one cradle:</li> <li>► Power Supply (PWR- BGA12V50W0WW</li> <li>► DC Line Cord (CBL-DC-388A1- 01)</li> <li>► AC Line Cord (23844-00-00R), or country specific version</li> <li>For charging up to 4 cradles from one power supply:</li> <li>► Power Supply (PWR- BGA12V108W0WW)</li> <li>► 4-Way DC Line Cord (CBL-DC- 380A1-01)</li> <li>► AC Line Cord (23844-00-00R</li> </ul>



CRD1S0T-RFD49-BASE-COM-1R		Single Slot Charge + Communication ShareCradle Base	<ul> <li>Includes Charge + Communication Base for attaching Cradle cup.</li> <li>Does not charge spare batteries.</li> <li>NOTE: Base accepts Charging cups using enhanced Zebra common ShareCradle design which allows the cup to be easily removed and swapped with different cups using a simple coin turned screw.</li> </ul>	<ul> <li>Cradle Cup</li> <li>For charging one cradle:</li> <li>Power Supply (PWR- BGA12V50W0WW</li> <li>DC Line Cord (CBL-DC-388A1- 01)</li> <li>AC Line Cord (23844-00-00R), or country specific version</li> <li>For charging up to 4 cradles from one power supply:</li> <li>Power Supply (PWR- BGA12V108W0WW)</li> <li>A-Way DC Line Cord (CBL-DC- 380A1-01)</li> <li>AC Line Cord (23844-00-00R</li> <li>USB Cable (25-124330-01R) for PC connection</li> </ul>
Multi-Device				
Part Number	Picture	Description	Notes	Required Items
CRD3S4T-RFD49-UNIV-CHG-1R		Multi-Slot Charging ShareCradle - Universal/3rd Party	<ul> <li>Cradle will charge up to three RFD40.</li> <li>Also charges up to four spare RFD40 batteries.</li> <li>Includes USB-A port on rear of cradle cups which are reserved for future enhancements.</li> <li>NOTE: Charging cup uses enhanced Zebra common ShareCradle design which allows the cup to be easily removed and swapped with different cups using a simple coin turned screw.</li> </ul>	<ul> <li>Power Supply (PWR-BGA12V108W0WW)</li> <li>DC Line Cord (CBL-DC-382A1-01)</li> <li>AC Line Cord (23844-00-00R)</li> </ul>
CRD3S4T-RFD40-EC5X-CHG-1R		Multi-Slot Charging ShareCradle - RFD40 and EC50/EC55	<ul> <li>Cradle will charge up to three RFD40 and EC50/EC55 pairings and supports:</li> <li>RFD40 charging by itself</li> <li>EC50/EC55 charging by itself</li> <li>Both RFD40 and EC50/EC55 when attached together</li> <li>Also charges up to four spare RFD40 batteries.</li> <li>NOTE: Charging cup uses enhanced Zebra common ShareCradle design which allows the cup to be easily removed and swapped with different cups using a simple coin turned screw.</li> </ul>	<ul> <li>Power Supply (PWR-BGA12V108W0WW)</li> <li>DC Line Cord (CBL-DC-382A1-01)</li> <li>AC Line Cord (23844-00-00R)</li> </ul>
CRD3S4T-RFD40-TC2X-CHG-1R		Multi-Slot Charging ShareCradle - RFD40 and TC21/TC26	<ul> <li>Cradle will charge up to three RFD40 and TC21/TC26 pairings and supports:</li> <li>RFD40 charging by itself</li> <li>TC21/TC26 charging by itself</li> <li>Both RFD40 and TC21/TC26 when attached together</li> <li>Also charges up to four spare RFD40 batteries.</li> <li>NOTE: Charging cup uses enhanced Zebra common ShareCradle design which allows the cup to be easily removed and swapped with different cups using a simple coin turned screw.</li> </ul>	<ul> <li>Power Supply (PWR-BGA12V108W0WW)</li> <li>DC Line Cord (CBL-DC-382A1-01)</li> <li>AC Line Cord (23844-00-00R)</li> </ul>



CRD3S4T-RFD49-UNIV-COM-1R	Multi-Slot Charge + Ethernet ShareCradle - Universal/3rd Party	<ul> <li>Cradle will charge up to three RFD40.</li> <li>Also provides Ethernet communications to each RFD40 to enable management, firmware updating and device health.</li> <li>Also charges up to four spare RFD40 batteries.</li> <li>Includes USB-A port on rear of cradle cups which are reserved for future enhancements.</li> <li>NOTE: Charging cup uses enhanced Zebra common ShareCradle design which allows the cup to be easily removed and swapped with different cups using a simple coin turned screw.</li> </ul>	<ul> <li>Power Supply (PWR- BGA12V108W0WW)</li> <li>DC Line Cord (CBL-DC- 382A1-01)</li> <li>AC Line Cord (23844-00- 00R)</li> </ul>
CRD3S4T-RFD40-EC5X-COM-1R	Multi-Slot Charge + Ethernet ShareCradle - RFD40 and EC50/EC55	<ul> <li>Cradle will charge up to three RFD40 and EC50/EC55 pairings and supports:</li> <li>RFD40 charging by itself</li> <li>EC50/EC55 charging by itself</li> <li>Both RFD40 and EC50/EC55 when attached together</li> <li>Also provides Ethernet communications to each RFD40 and EC50/EC55 to enable management, firmware updating and device health.</li> <li>Also charges up to four spare RFD40 batteries.</li> <li>NOTE: Charging cup uses enhanced Zebra common ShareCradle design which allows the cup to be easily removed and swapped with different cups using a simple coin turned screw.</li> </ul>	<ul> <li>Power Supply (PWR-BGA12V108W0WW)</li> <li>DC Line Cord (CBL-DC-382A1-01)</li> <li>AC Line Cord (23844-00-00R)</li> </ul>
CRD3S4T-RFD40-TC2X-COM-1R	Multi-Slot Charge + Ethernet ShareCradle - RFD40 and TC21/TC26	<ul> <li>Cradle will charge up to three RFD40 and TC21/TC26 pairings and supports:</li> <li>RFD40 charging by itself</li> <li>TC21/TC26 charging by itself</li> <li>Both RFD40 and TC21/TC26 when attached together</li> <li>Also provides Ethernet communications to each RFD40 and TC21/TC26 to enable management, firmware updating and device health.</li> <li>Also charges up to four spare RFD40 batteries.</li> <li>NOTE: Charging cup uses enhanced Zebra common ShareCradle design which allows the cup to be easily removed and swapped with different cups using a simple coin turned screw.</li> </ul>	<ul> <li>Power Supply (PWR-BGA12V108W0WW)</li> <li>DC Line Cord (CBL-DC-382A1-01)</li> <li>AC Line Cord (23844-00-00R)</li> </ul>
CRD3S4T-RFD49-BASE-CHG-1R	Multi-Slot Charging ShareCradle Base	<ul> <li>Includes Charge-Only Base for attaching up to three Cradle cups.</li> <li>Includes pre-installed 4-Slot Battery Charger for charging up to four spare RFD40 batteries.</li> <li>NOTE: Base accepts Charging cups using enhanced Zebra common ShareCradle design which allows the cup to be easily removed and swapped with different cups using a simple coin turned screw.</li> </ul>	<ul> <li>► Three Cradle Cups</li> <li>► Power Supply (PWR- BGA12V108W0WW)</li> <li>► DC Line Cord (CBL-DC-382A1- 01)</li> <li>► AC Line Cord (23844-00-00R)</li> </ul>



CRD3S4T-RFD49-BASE-COM-1R		Multi-Slot Charge + Ethernet ShareCradle Base	<ul> <li>Includes Charge + Communication Base for attaching up to three Cradle cups.</li> <li>Also provides Ethernet communications to each RFD40 and mobile computer to enable management, firmware updating and device health.</li> <li>Includes pre-installed 4-Slot Battery Charger for charging up to four spare RFD40 batteries.</li> <li>NOTE: Base accepts Charging cups using enhanced Zebra common ShareCradle design which allows the cup to be easily removed and swapped with different cups using a simple coin turned screw.</li> </ul>	<ul> <li>► Three Cradle Cups</li> <li>► Power Supply (PWR- BGA12V108W0WW)</li> <li>► DC Line Cord (CBL-DC-382A1- 01)</li> <li>► AC Line Cord (23844-00-00R)</li> </ul>
Cradle Accessories				
Part Number	Picture	Description	Notes	Required Items
CUP-RFD49-UNIV-1R		Cradle Cup for RFD40, Universal/3rd Party	<ul> <li>Cup can be installed on Single Slot SharedCradle Base or Multi-Slot ShareCradle Base.</li> <li>Provides Charge-Only support or Charge+Communications support for an RFD40 unit, depending on which Cradle Base type installed on.</li> <li>Includes USB-A port on rear of cup which is reserved for future enhancements.</li> <li>Cup uses enhanced Zebra common ShareCradle design which allows the cup to be easily removed and swapped with different cups using a simple coin turned screw.</li> </ul>	ShareCradle Base
CUP-RFD40-EC5X-1R	RDA	Cradle Cup for RFD40 and EC50/EC55	<ul> <li>Cup can be installed on Single Slot SharedCradle Base or Multi-Slot ShareCradle Base.</li> <li>Provides Charge-Only support or Charge+Communications support for an RFD40 and/or EC50/EC55 unit, depending on which Cradle Base type installed on.</li> <li>Cup uses enhanced Zebra common ShareCradle design which allows the cup to be easily removed and swapped with different cups using a simple coin turned screw.</li> </ul>	ShareCradle Base
CUP-RFD40-TC2X-1R	Hone Hone	Cradle Cup for RFD40 and TC21/TC26	<ul> <li>Cup can be installed on Single Slot SharedCradle Base or Multi-Slot ShareCradle Base.</li> <li>Provides Charge-Only support or Charge+Communications support for an RFD40 and/or TC21/TC26 unit, depending on which Cradle Base type installed on.</li> <li>Cup uses enhanced Zebra common ShareCradle design which allows the cup to be easily removed and swapped with different cups using a simple coin turned screw.</li> </ul>	ShareCradle Base



Zapraszamy	do kontaktu!
Więcej informac	ji: www.kreski.pl

BRKT-SCRD-SMRK-01		Multi-Slot ShareCradle Wall/Rack Mount Bracket	<ul> <li>Allows for rack and wall mounting of one Multi-Slot ShareCradle or up to four Single-Slot ShareCradles.</li> <li>Bracket can be mounted on standard 19" network rack or on a wall.</li> <li>Cable routing slots &amp; removable power supply holder tray.</li> <li>Adjustable tabs &amp; screw mounts for easy hanging/installation.</li> <li>Adjustable orientations - horizontal, vertical, angled.</li> <li>See the Bluetooth-Generic Accessories TAG for info on 3rd party Network Racks that can be used for mounting this bracket.</li> </ul>	
ADP-TC7X-PLT-FX		5-Slot ShareCradle Mounting Bracket Adapter Plate for Honeywell	<ul> <li>Allows Zebra Multi-Slot ShareCradles to be mounted on legacy Honeywell</li> <li>Flex Cradle Wall Mount Brackets (HON SKU #203-641-002).</li> <li>Includes hardware to attach plate to HON wall bracket and secure</li> <li>ShareCradle to plate.</li> <li>NOTE: This is a custom product.</li> <li>Please work with your Zebra representative to open a Custom</li> <li>Product Request (CPR) if you would like to order this cable.</li> </ul>	
Battery Charging				
Part Number	Picture	Description	Notes	Required Items
SAC-TC8X-4SCHG-01	MA		►Charges up to four spare batteries. ►Can be used standalone or up to four	To power single 4-slot Charger: ► Power Supply (PWR- BGA12V50W0WW) ► DC Line Cord (CBL-DC-388A1- 01) ► AC Line Cord (23844-00-00R) or country specific version
		4-Slot Battery Charger	chargers can be installed on Multi-Stot Wall/Rack Mount Bracket (BRKT-SCRD- SMRK-01)	To power two sets of 4-slot Chargers from one power supply: ▶ Power Supply (PWR- BGA12V108W0WW) ▶ DC Y-Cable Line Cord (CBL-DC- 523A1-01) ▶ AC Line Cord (23844-00-00R) or country specific version
Charge/Communication (	Cables	4-Slot Battery Charger	chargers can be installed on Multi-Slot Wall/Rack Mount Bracket (BRKT-SCRD-	Chargers from one power supply: ▶ Power Supply (PWR- BGA12V108W0WW) ▶ DC Y-Cable Line Cord (CBL-DC- 523A1-01) ▶ AC Line Cord (23844-00-00R) or
Charge/Communication ( Part Number	Cables	4-Slot Battery Charger Description	chargers can be installed on Multi-Slot Wall/Rack Mount Bracket (BRKT-SCRD-	Chargers from one power supply: ▶ Power Supply (PWR- BGA12V108W0WW) ▶ DC Y-Cable Line Cord (CBL-DC- 523A1-01) ▶ AC Line Cord (23844-00-00R) or



CBL-TC2X-USBC-01		USB-C cable	<ul> <li>▶ to be discontinued 10/2021, see PME 10621</li> <li>▶ USB-A to USB-C cable</li> <li>▶ Connects directly to USB-C port on RFD40 to charge device and allows the RFD40 to be used as a tethered RFID reader.</li> <li>▶ Cable length is 1.5M (~5 ft.)</li> <li>▶ This cable includes an additional ferrite bead and is typically used with TC25 devices.</li> </ul>	
3rd party *		USB-C cable	► Connects directly to USB-C port on RFD40 to charge device and allows the RFD40 to be used as a tethered RFID reader.	
25-124330-01R		Single Slot Cradle to PC/Host USB cable	<ul> <li>Used with Single Slot ShareCradles</li> <li>Micro USB connection on cradle end</li> </ul>	
CBL-RFD49-USB1-01	coming soon	Snap-on USB Communication/Charging Cable	<ul> <li>Attaches to charge/communicator port on bottom of RFD40 and allows the RFD40 to be used as a tethered RFID reader.</li> <li>Will charge battery in RFD40 from 0- 90% in as little as X.X hours when used with USB Power Supply (PWR- WUA5V12W0xx)</li> </ul>	Eor standalone charging: Indoor use: order Country Specific version of USB Power Supply (PWR-WUA5V12W0xx) In Vehicle use: USB Cigarette Lighter Adapter (CHG-AUTO-USB1-01)
Device Adapters				
Part Number	Picture	Description	Notes	Required Items
ADP-RFD40-BLNK-1R		Replacement Blank Cover for eConnex™ Adapter Slot	<ul> <li>This is a spare/replacement cover that typically ships with each RFD40 unit.</li> <li>Cover snaps into place on RFD40 unit.</li> </ul>	



ADP-RFD40-EC5X-1E		eConnex™ Adapter for EC50/EC55	<ul> <li>▶ Allows EC50/EC55 to be mounted on top of RFD40 and communicate directly to the reader.</li> <li>▶ Requires EC50/EC55 configuration with 8-Pin Connector Back I/O connector.</li> <li>▶ Adapter also allows both the RFD40 and EC50/EC55 to be docked as a pair in Single or Multi-Slot ShareCradles.</li> </ul>	
ADP-RFD40-TC2X-1E	TC2:00	eConnex™ Adapter for TC21/TC26	<ul> <li>Allows TC21/TC26 to be mounted on top of RFD40 and communicate directly to the reader.</li> <li>Requires TC21/TC26 configuration with 8-Pin Connector Back I/O connector.</li> <li>Adapter also allows both the RFD40 and TC21/TC26 to be docked as a pair in Single or Multi-Slot ShareCradles.</li> </ul>	
SG-RFD49-ADPSCRWS-01	9 9 9	Replacement Screws for eConnex™ Adapters	► Includes four screws which are included with each eConnex™ Adapter.	
Power Cords/Power Sup	plies			
Part Number	Picture	Description	Notes	Required Items
CBL-DC-388A1-01		DC Power Cord	<ul> <li>► Used along with Power Supply PWR- BGA12V50W0WW to power Single Slot ShareCradles or Spare Battery Charger.</li> <li>► Cable length is 1.8 meters</li> </ul>	
PWR-BGA12V50W0WW		Power Supply	<ul> <li>► Used to power Single Slot ShareCradles.</li> <li>► 100-240 VAC,12V, 4.16A, 50W</li> <li>► Provides US DOE Level VI compliance for power efficiency.</li> <li>► Replaces PWRS-14000-148R and PWRS-14000-148C</li> </ul>	<ul> <li>DC Line Cord (CBL-DC- 388A1-01)</li> <li>AC Line Cord (23844-00- 00R) or country specific version</li> </ul>



KIT-PWR-12V50W		Power Supply Kit	<ul> <li>Includes Power Supply (PWR- BGA12V50W0WW) and DC Line Cord (CBL-DC-388A1-01)</li> <li>Used to power Single Slot ShareCradles.</li> </ul>	► AC Line Cord (23844-00- 00R) or country specific version
PWRS-14000-148C		Power Supply with integrated DC Cord (for RFD8500 cradle)	<ul> <li>Has additional ferrite from KT-14000-148R to provide additional noise supression.</li> <li>Used to power Universal Cradle (for RFD8500)</li> <li>100-240 VAC,12VDC,3.33A</li> <li>Energy Star Compliant</li> <li>Discontinued 2/2017, now use PWR-BGA12V50W0WW and CBL-DC-388A1-01.</li> </ul>	► AC Line Cord (23844-00- 00R) or country specific version
PWRS-14000-148R		Power Supply with integrated DC Cord (for RFD8500i cradle)	<ul> <li>Discontinued 1/2017, now use PWR-BGA12V50W0WW and CBL-DC-388A1-01 - see PMB 2923 and PMB 2851.</li> <li>Replaces KT-14000-148R</li> <li>Used to power Single Slot ShareCradles.</li> <li>100-240 VAC,12VDC,3.33A</li> <li>Energy Star Compliant</li> </ul>	►AC Line Cord (23844-00- 00R) or country specific version
50-14000-148R		Power Supply with integrated DC Cord (for RFD8500i cradle)	<ul> <li>Discontinued 12/2007 - replaced by KT-14000-148R</li> <li>Used to power Single Slot ShareCradles.</li> </ul>	► AC Line Cord (23844-00- 00R) or country specific version
KT-14000-148R		Power Supply with integrated DC Cord (for RFD8500i cradle)	<ul> <li>Replaces 50-14000-148R</li> <li>Used to power Single Slot</li> <li>ShareCradles.</li> <li>Discontinued 12/2010 - now use</li> <li>PWRS-14000-148R</li> </ul>	► AC Line Cord (23844-00- 00R) or country specific version
CBL-DC-381A1-01		DC Power Cord	<ul> <li>Used with Power Supply PWR- BGA12V108W0WW to power Multi-Slot ShareCradles.</li> <li>This cable does not include the black extension release latch which is not required when used on Multi-Slot ShareCradles.</li> </ul>	
CBL-DC-382A1-01		DC Power Cord	<ul> <li>Used with Power Supply PWR- BGA12V108W0WW to power Multi-Slot ShareCradles.</li> <li>Cable has black extension tab for releasing the cable from the back of the cradle. This isn't required when using Multi-Slot ShareCradles.</li> <li>NOTE: CBL-DC-381A1-01 is the recommended cable to be used.</li> </ul>	
50-16002-029R		DC Power Cord	<ul> <li>Used with Power Supply PWRS- 14000-241R to power Multi-Slot ShareCradles.</li> <li>Discontinued 2/2017, now use CBL- DC-382A1-01 - PMB 2851 and 2933</li> </ul>	
CBL-DC-523A1-01	0	2-Way DC Y Power Cord	► Used to power two 4-Slot Battery Chargers from one Power Supply (PWR- BGA12V108W0WW)	



25-85993-01R	Ø	2-Way DC Y Power Cord	<ul> <li>► Used to power two 4-Slot Battery Chargers from one Power Supply (PWRS-14000-241R)</li> <li>► Discontinued 2/2017, now use CBL- DC-523A1-01 - PMB 2851 and 2933</li> </ul>	
CBL-DC-380A1-01		4-Way Power Cable	► Used with Power Supply PWR- BGA12V108W0WW for powering up to four Single Slot Cradles.	
25-85992-01R		4-Way Power Cable	<ul> <li>Discontinued 2/2017, now use CBL-DC-380A1-01 - see PMB 2851 and PMB 2933</li> <li>Used with Power Supply PWR-BGA12V108W0WW for powering up to four Single Slot Cradles.</li> </ul>	
PWR-BGA12V108W0WW		Power Supply	<ul> <li>► Used to power Multi-Slot ShareCradles.</li> <li>► 100-240 VAC, 12V, 9A, 108W</li> <li>► Provides US DOE Level VI compliance for power efficiency.</li> <li>► Replaces PWRS-14000-241 R</li> <li>► Replaces 50-14000-241 R</li> </ul>	<ul> <li>DC Power Cable (CBL-DC- 382A1-01) or 4-Way Power Cable (CBL-DC-380A1-01)</li> <li>AC Line Cord (23844-00- 00R) or country specific</li> </ul>
PWRS-14000-241R		Power Supply	<ul> <li>► Used to power Multi-Slot</li> <li>► Used to power Multi-Slot</li> <li>► 100-240VAC,12VDC,9A</li> <li>► Energy Star Compliant</li> <li>► Discontinued 2/2017, now use PWR-BGA12V108W0WW - PMB 2851 and 2022</li> </ul>	DC Power Cable (50-16002- 029R) or 4-Way Power Cable (25-85992-01R) and 23844-00-00R
50-14001-004R		Power Supply	<ul> <li>Discontinued 12/2007 - replaced by 50-14000-241R</li> <li>Used to power Multi-Slot ShareCradles.</li> </ul>	DC Power Cable (50-16002- 029R) or 4-Way Power Cable (25-85992-01R) and ▶ AC Line Cord (23844-00- 00R) or country specific version
50-14000-241R		Power Supply	<ul> <li>Replaces 50-14001-004R</li> <li>Used to power Multi-Slot</li> <li>ShareCradles.</li> <li>Discontinued 12/2010 - now use</li> <li>PWRS-14000-241R</li> </ul>	DC Power Cable (50-16002- 029R) or 4-Way Power Cable (25-85992-01R) and ►AC Line Cord (23844-00- 00R) or country specific version
23844-00-00R		AC Line Cord	► This AC Line Cord is for use in North America. See the <b>AC Line Cords by</b> <b>Country</b> TAG for comparable line cords to use in other countries.	
PWR-WUA5V6W0WW		USB Power Supply	<ul> <li>Includes four international plugs for use in US, UK, EU, and AU. Additional plugs can be purchased separately for other countries.</li> <li>5.2V, 1.2A, 6W output</li> <li>Provides US DOE Level VI compliance for power efficiency</li> </ul>	USB-C Cable or Snap-On Charge/Communication Cable (CBL-RFD49-USB1-01)
CN-000803-01	٠	Spare/Replacement USB Power Supply AC Clip for Australia (AUS)	<ul> <li>This AC Clip is normally included with PWR-WUA5V6W0WW</li> <li>2 pin Australia plug</li> </ul>	USB Power Supply (PWR- WUA5V6W0WW)



adprobading (	ao itorrealtean
Więcej informacj	i: www.kreski.pl

	USB Power Supply AC Clip for Argentina (ARG)		USB Power Supply (PWR- WUA5V6W0WW)			
	USB Power Supply AC Clip for Korea (KOR)		USB Power Supply (PWR- WUA5V6W0WW)			
4	Spare/Replacement USB Power Supply AC Clip for US (US)	<ul> <li>This AC Clip is normally included with</li> <li>PWR-WUA5V6W0WW</li> <li>2 pin US plug</li> </ul>	USB Power Supply (PWR- WUA5V6W0WW)			
-	<u>Spare/Replacement</u> USB Power Supply AC Clip for Europe (EU)	► This AC Clip is normally included with PWR-WUA5V6W0WW	USB Power Supply (PWR- WUA5V6W0WW)			
	<u>Spare/Replacement</u> USB Power Supply AC Clip for UK (UK)	► This AC Clip is normally included with PWR-WUA5V6W0WW	USB Power Supply (PWR- WUA5V6W0WW)			
	USB Power Supply AC Clip for China (CHN)	►straight pins China plug	USB Power Supply (PWR- WUA5V6W0WW)			
	USB Power Supply AC Clip for Brazil (BRA)	▶2 pin Brazil plug	USB Power Supply (PWR- WUA5V6W0WW)			
	USB Power Supply AC Clip for India (IND)		USB Power Supply (PWR- WUA5V6W0WW)			
	USB Power Supply	<ul> <li>Power Supply</li> <li>Includes four international plugs for US, UK, EU, and AU</li> <li>5V, 1.2A output</li> <li>Discontinued 3/2017, now use PWR- WUA5V6W0WW</li> </ul>	USB-C Cable or Snap-On Charge/Communication Cable (CBL-RFD49-USB1-01)			
Batteries						
Picture	Description	Notes	Required Items			
	RFD40 Spare/Replacement Battery (7000 mAh) with PowerPrecision <b>Plus</b>	<ul> <li>This is the standard battery that is included with each RFD40 unit.</li> <li>Provides 8 hours of continous usage.</li> <li>Battery is same form factor as TC8X series devices, but is labeled differently for regulatory compliance. TC8X series batteries should not be used in the RFD40.</li> </ul>				
	Picture	Image: for Argentina (ARG)Image: for Argentina (ARG)Image: for Korea (KOR)Image: for Korea (Kore	for Argentina (ARG)         Image: Second Stream (KOR)         Image: Se			

SG-RFD40-LOCKFT-01	4		► Foot screws onto bottom of device to prevent battery from being removed.	
--------------------	---	--	--	--



Zapraszamy do kontaktu! Więcej informacji: www.kreski.pl